



Application Instructions

WoodShield Interior WoodStain Varnish

Where to use

Properly prepared, stained, or previously varnished interior wood substrates such as floors, doors, trim, paneling, cabinets, or furniture.

Preparation

Surfaces should be clean, dry, sound and free from dirt, dust, and surface contaminants. Sand substrates first, using either fine sand paper, or a fine sanding pad. DO NOT use steel wool. Always sand in the direction of the natural grain. For varnishing hardwood floors, we recommend a lamb's wool applicator. Remove sanding dust with lightly water- dampened cloth, or tack rag. Always prepare a test sample on a scrap piece of wood before you begin to ensure a sound technique and to achieve a greater product performance. Although most varnish products share some similarities and characteristics, all vary slightly from one to another.

Coverage

Maximum spread rate is 100-125 sq ft per quart or 400-500 sq. ft. per gallon depending on substrate porosity.

Application

Do not thin. Stir gently and thoroughly before use and continue stirring during application. Intermix if using multiple containers to assure sheen uniformity. May be applied using a high quality synthetic brush. If using a brush, maintain a wet edge and do not allow the product to puddle. Do not over brush. Use a lamb's wool applicator for floors. Allow 2-4 hours after staining before applying a clear coat. Dries to the touch in 15-30 minutes. May be recoated in 2-4 hours. Finish with a minimum of two coats of WoodShield varnish. For maximum protection and durability, apply a third coat. Avoid applying at temperatures below 41°F (5°C).

Clean up

Clean hands and equipment with warm soapy water.

Storage

Protect from freezing

Disposal

Dispose of in accordance with local ordinance.

Health & safety

Avoid contact with skin and eyes. Wash off splashes with water. Keep out of reach of children. Do not ingest.